# RAD 330

## Power Issue

- Is it plugged in?
- Has the breaker been tripped?

## Filter Issue

- The Filter Should be cleaned weekly for high volume use
- How to clean the filter
    1. Unscrew the filter housing
    2. Remove the screen
    3. Rinse off with water to thoroughly clean
    4. Reinstall filter and screw housing back on

## Temperature Issue

- See Coolbot Instructions
- Check the temperature when the room LED is lit. Push the check mark and "set temperature" will flash. Push left and right arrows to change to 37°. Tap √ to confirm.
- Check fin setting- push the right arrow until the LED is on the fins and push the √ to see the setting. It should read "02", use left and right arrows to change if not correct. Push the √ again to set on "02" and return to the home screen.
- Heater setting- push the right arrow until you get to the heater setting. Hold down the √ until the display flashes and it should read D2. Use left and right arrows to change if not correct. Push the √ again to set on "02" and return to the home screen.

## Pump Issue

- Pump not picking up product? Check the filter and power
- Meter not registering
    - Check the batteries: Remove the display housing by unscrewing the four small screws. Replace with new batteries.
    - Rinse Meter: Remove the display housing by unscrewing the four small screws. Rinse remaining discharge value.
- Circulation Timer
    - The time must be set to the correct time in order for the timer to work properly.
    - It should be set to circulate product 1 minute every 4 hours starting at 5:00am and ending at 9:00pm.
    - See instructions

## Still have issues?  E-mail: Service@Holganix.com

## Call: 866-563-2784