


## **RAD 600 INSTRUCTIONS**

- 1. Determine how many gallons of Holganix is needed for your fill.
- 2. Open Yellow Fill Valve A & B to "FILL" position.
- 3. Reset GPI Meter by holding button down while on "TOTAL 1" setting until you "zero out" the GPI meter.
- 4. Hold Momentary Switch on until desired gallons is reached on meter.
- 5. Turn yellow valves to "OFF" position IMPORTANT!!!
- 6. See Inductor Bowl Instructions.

\*\*\*FOR JUG FILL

- 1. Follow Step 1 above
- 2. Open Yellow Valve A and Hose Valve (keep Yellow Valve B closed)
- 3. Follow steps 3 through 6 above



Any questions or concerns, please call Holganix at 866-563-2784 or email SUPPORT@holganix.com

YELLOW